


# INSTALLATION

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc., 2014



# INSTRUCTIONS

These instructions show the general installation sequence and procedure for typical installation.  
They supplement the shop detail and notations on installation and glazing.

<b>SECTION</b>	<b>PAGE</b>	
<b>I</b>	<b>3</b>	<b>GENERAL NOTES</b>
<b>II</b>	<b>4-7</b>	<b>PARTS IDENTIFICATION / TAKEOFF GUIDE</b>
<b>III</b>	<b>8-10</b>	<b>BASIC FRAMING DETAILS</b>
<b>IV</b>	<b>11-39</b>	<b>FRAME FABRICATION</b>
<b>V</b>	<b>40-47</b>	<b>FRAME ASSEMBLY</b>
<b>VI</b>	<b>48-51</b>	<b>FRAME INSTALLATION</b>
<b>VII</b>	<b>52, 53</b>	<b>GLAZING</b>
<b>VIII</b>	<b>54</b>	<b>DOOR STOP INSTALLATION</b>
<b>IX</b>	<b>55</b>	<b>TRANSOM AREA GLASS STOP INSTALLATION</b>
<b>X</b>	<b>56</b>	<b>GLASS SIZING FORMULA</b>

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc., 2014

## HANDLING, STORING, AND PROTECTION OF ALUMINUM




























The material must be protected against damage. The following precautions are recommended to assure early acceptance of your products and workmanship.

- A. HANDLE CAREFULLY-** Do not drop from the truck. Stack with adequate separation so material will not rub together. Store off the ground. Protect against elements and other construction trades. Work safely - always wear proper personal protective equipment. Wear hand protection to prevent injury due to sharp edges of cut extrusions.
- B. KEEP MATERIAL AWAY FROM WATER, MUD, AND SPRAY -** Prevent cement, plaster, or other materials from damaging the finish.
- C. PROTECT THE MATERIALS AFTER ERECTION -** Protect by wrapping with Kraft paper or by erecting Visqueen or canvas splatter screen. Cement, plaster, terrazzo, and other alkaline solutions and acid based materials used to clean masonry are very harmful to the finish and should be removed with water and mild soap IMMEDIATELY.

## GENERAL INSTALLATION NOTES











The following practices are recommended for all installations:

- A. CHECK SHOP DRAWINGS, INSTALLATION INSTRUCTIONS and GLAZING INSTRUCTIONS** to become thoroughly familiar with the project. The SHOP DRAWINGS take precedence and include specific details for the project. The INSTALLATION INSTRUCTIONS are of a general nature and cover the most common conditions.
- B. All materials are to be INSTALLED PLUMB, LEVEL, and TRUE.**
- C. All work should start from bench marks and/or column lines as established by the ARCHITECTURAL DRAWINGS and the GENERAL CONTRACTOR.** Check mullion spacing from ends of masonry opening to prevent dimensional build-up of day light opening.
- D. Make certain that the construction and openings which will receive your materials are in accordance with the contract documents.** If not, notify the GENERAL CONTRACTOR IN WRITING and resolve the differences before proceeding with your work.
- E. Isolate all aluminum to be placed directly in contact with uncured masonry or incompatible materials with a heavy coat of zinc chromate or bituminous paint.**
- F. Check all materials on arrival for quantity and be sure you have everything required to begin installation.**
- G. Sealants must be compatible with all materials with which they have contact, including other sealant surfaces.** Consult with sealant manufacturer for recommendations relative to joint size, shelf life, compatibility, priming, tooling, adhesion, etc.
- H. FASTENING - "Fastening" means any method of securing one part to another or to adjacent materials.** These instructions specify only those fasteners used within the system. Due to varying perimeter conditions and job performance requirements, perimeter anchor fasteners are not specified in these instructions. For perimeter anchor fastening, refer to the Shop Drawings or Engineering Calculations.
- I. CHECK OPENINGS - Make certain that the opening which will receive your materials is in accordance with the contract documents.** If not, notify the General Contractor in writing and resolve differences before proceeding with your work.
- J. BUILDING CODE - Building and glazing codes governing the design and use of products vary widely.** Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility for these design considerations. It is the responsibility of the owner, specifier, architect, general contractor and the installer to make these selections in strict conformance with all applicable codes.
- K. GASKET INVENTORY ROTATION - These high quality rubber extrusions are coated with silicone lubricant, Silicone will dry over time leaving a white "chalky" residue.** Please rotate your stock "FIRST IN - FIRST OUT". If the rubber becomes dry, you may use water ONE TIME to reconstitute the silicone, after that, use a soap water solution.

ILLUSTRATION	NO.	DESCRIPTION	ILLUSTRATION	NO.	DESCRIPTION
	027366 (EPDM) 027366SI (Silicone)	SETTING BLOCK		530011	HORIZONTAL / SILL OPEN BACK
	027074	STANDARD PUSH-ON GASKET		530015	PARTITION SILL
	027076	LIGHT PUSH-ON GASKET		530016	HEAD / JAMB / STACK VERTICAL
	027077	HEAVY PUSH-ON GASKET		530019	4" HORIZONTAL / SILL
	027084	"W" BLOCK		530020	HEAD / DOOR JAMB
	027633	1/2" DIA. HOLE PLUG		061222	2" X 6" TUBE
	027860	BULB GASKET (Used with 530021)		530018	GLASS STOP
	028856	#12 X 1-1/8" PHTF TYPE "AB" (Spline Screw)		530012	SHALLOW POCKET FILLER
	069177	CONCEALED SCREW APPLIED DOOR STOP		530013	FLAT POCKET FILLER
#8 x 3/8 inch PHST type AB applied door stop illustration" data-bbox="93 641 128 656"/>	028260	#8 X 3/8" PHST TYPE "AB" (For Applied Door Stop)		530022	SHALLOW POCKET
	279001	APPLIED SASH GUTTER		530023	DEEP POCKET FILLER
	450022	APPLIED SASH STOP		530024	DEEP POCKET FILLER
	128345	#10 X 9/16" FHTF TYPE B (For Applied Sash)		530301	SHIM SUPPORT 3" LONG
	530010	VERTICAL MULLION		530017	SNAP-IN STOP

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

ILLUSTRATION	NO.	DESCRIPTION	ILLUSTRATION	NO.	DESCRIPTION
	530021	SNAP-IN STOP			
	530504	SNAP-IN STOP (530021) WITH GASKET (027860)			
	050761	C.O.C. MOUNTING BRACKET			
	450506	SINGLE ACTING T-BAR CLIP PKG.			
	451548	SHEAR BLOCK PKG. FOR S/A O/P C.O.C.			
	451549	SHEAR BLOCK PKG. FOR S/A B/H C.O.C.			
	530501	ANGLE CLIP PKG. FOR COMMON STRIKE JAMB			
	530502	HEAD CLIP PKG. FOR COMMON STRIKE JAMB			
	530503	SILL CLIP PKG. FOR COMMON STRIKE JAMB			
	530200	DRILL FIXTURE			

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

**SCREW SPLINE FRAMING**

Mullion	530010
Shallow Pocket Filler	530012
Shallow Pocket Filler	530022
Deep Pocket Filler	530023
Deep Pocket Filler	530024
Vertical Mullion/Head	530016
Horizontal/Sill Open Back	530011
Horizontal/Sill	530015
Horizontal 4" High Sidelite Sill	530019
Snap-in Stop with Gasket	530504 (INCLUDES 530021 & 027860)
Snap-in Stop	530017
Glass Stop	530018
Spline Screw	028856
Drill Jig	530200

**MISCELLANEOUS**

Flat Filler	530013
-------------	--------

**DOOR FRAMING**

Common Door Jamb	061222
Door Jamb with Snap-in Stop	530020
Applied Sash Gutter	279001
Glass Stop	450022
Applied Sash Fastener	128345
1" Door Stop Package	069177
Common Door Jamb Angle Clip at Head	530501
Common Door Jamb Clip at Head	530502
Common Door Jamb Clip at Floor	530503
Transom Bar/Header Shear Block	450506
O/P COC Transom Bar/Header Shear Block	451548
B/H COC Transom Bar/Header Shear Block	451549

**GLAZING MATERIALS**

Setting Block	027366
"W" Side Block	027084
Standard Push-in Gasket *	027074
Light Push-in Gasket *	027076
Heavy Push-in Gasket *	027077

\* **NOTE: Reference page 53 for gasket combinations with available infills.**

**ANCHORS**

Flat Filler / Shim Support (3" Long)	530301
--------------------------------------	--------

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014


FRAMING MEMBERS	CUT FORMULA
JAMB	FRAME HEIGHT
INTERMEDIATE MULLION	FRAME HEIGHT - 3.049"
INTERMEDIATE MULLION POCKET FILLER	FRAME HEIGHT - 4.000"
STACK MULLION	FRAME HEIGHT
STACK MULLION POCKET FILLER (W/ Standard Sill)	FRAME HEIGHT - 1.000"
STACK MULLION POCKET FILLER (W/ Partition Sill)	FRAME HEIGHT - 1.750"
HEAD	TOTAL DLO + (No. of VERT. MULLIONS x 2")
HORIZONTAL	DLO
SILL / PARTITION SILL	TOTAL DLO + (No. of VERT. MULLIONS x 2")
GLASS STOP (Sill / Horizontal)	DLO - 1/16"
SNAP-IN STOP (Head / Partition Sill)	TOTAL DLO + (No. of VERT. MULLIONS x 2")
SNAP-IN STOP (At Door Header)	DOOR OPENING WIDTH
SNAP-IN STOP (Jamb / Stack Mullion / Door Jamb)	FRAME HEIGHT
DOOR JAMB	FRAME HEIGHT
DOOR JAMB POCKET FILLER (With Standard Sill)	FRAME HEIGHT - 1.000"
DOOR JAMB POCKET FILLER (With Partition Sill)	FRAME HEIGHT - 1.750"
COMMON DOOR JAMB WITH DOOR HEADER	FRAME HEIGHT
CRIPPLE COMMON DOOR JAMB AT T-BAR	DOOR OPENING HEIGHT
CRIPPLE COMMON DOOR JAMB AT TRANSOM HEAD	FRAME HEIGHT - 2"
DOOR HEADER	DOOR OPENING WIDTH
TRANSOM BAR	DOOR OPENING WIDTH
TRANSOM BAR WITH CRIPPLE DOOR JAMB	(DR OPENING WIDTH x 2) + 2"

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.





Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014


This framing system is designed to be fabricated and assembled on the floor in bays, then each bay is raised into the opening position and joined with the next bay. Once elevation is anchored into the opening, the head, jambs and partition sill members are captured with a snap-in face member to secure the entire opening.






ELEVATIONS ARE NUMBER KEYED TO DETAILS



NOTE:  
EVERY UNIT MUST HAVE AT LEAST ONE DEEP VERTICAL POCKET TO INSTALL GLAZING.



STACK VERTICAL IS REQUIRED WHEN FRAME IS OVER 20'-0" WIDE. ALSO USED AT TRANSITION TO PARTITION WALL.




Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.


© Kawneer Company, Inc. 2014






ELEVATIONS ARE NUMBER KEYED TO DETAILS


SS = SCREW SPLINE  
SB = SHEAR BLOCK




7 HEAD AT DOOR




8 HEAD AT COMMON DOOR JAMB




9 TRANSOM HEAD AT COMMON DOOR JAMB




10 TRANSOM BAR W/ COC OR SURFACE CLOSER




10 TRANSOM BAR W/ COC FOR LCN CLOSER



10 TRANSOM BAR W/ COC FOR STD. KAWNEER CLOSER



11 HEAD CLIP AT COMMON DOOR JAMB




12 SILL CLIP AT COMMON DOOR JAMB


Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.


© Kawneer Company, Inc. 2014




ELEVATIONS ARE NUMBER KEYED TO DETAILS




13 DOOR JAMB




15 DOOR JAMB




17 DOOR JAMB




19 COMMON DOOR JAMB




14 TRANSOM JAMB



16 TRANSOM JAMB



18 TRANSOM JAMB



20 COMMON TRANSOM JAMB

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014


**STEP A: SCREW SPLINE HOLE PREPS**

Cut vertical members to required length (Frame Height). At horizontal locations drill the required holes in the vertical member to attach spline screws using (530200) Drill Jig as shown below.

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014



**JAMB PREPARATION**


Cope top of jamb as shown below.

Bottom of jamb is square cut.

Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in jamb at required locations.

Cope top of the snap-in stop as shown below.

Bottom of snap-in stop is square cut.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.





Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

**JAMB PREPARATION AT PARTITION WALL**

Cope the top and bottom of jamb as shown below.

Using the 530200 drill jig, drill 0.228 dia. holes for spline screws in jamb at required locations.

Cope the top and bottom of snap-in stop as shown below.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

**INTERMEDIATE VERTICAL PREPARATION**



Top of vertical is square cut.

Cope bottom of vertical as shown below.


Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in vertical at required locations.

Top and bottom of pocket filler is square cut.


Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in pocket filler at required locations.



TOP



BOTTOM



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

**INTERMEDIATE VERTICAL PREPARATION AT PARTITION WALL**



Top of vertical is square cut.

Cope bottom of vertical as shown below.


Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in vertical at required locations.

Top and bottom of pocket filler is square cut.


Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in pocket filler at required locations.



TOP



BOTTOM



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014


**STACK INTERMEDIATE VERTICAL PREPARATION**

Cope top of intermediate vertical as shown below.

Bottom of vertical is square cut.

Using the 530200 drill jig, drill 0.228 dia. holes for spline screws in vertical at required locations.

Cope top of snap-in stop as shown below, bottom of stop is square cut.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.


Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014



**STACK INTERMEDIATE VERTICAL PREPARATION (Cont.)**

Top and bottom of snap-in stop is square cut.

Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in vertical at required locations.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

**STACK INTERMEDIATE VERTICAL PREPARATION AT PARTITION WALL**


Cope top of intermediate vertical as shown below.

Bottom of vertical is square cut.

Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in vertical at required locations.

Cope top of snap-in stop as shown below, bottom of stop is square cut.

Weathering must be cut back to bottom of sill snap-in stop at partition wall.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014


**STACK INTERMEDIATE VERTICAL PREPARATION AT PARTITION WALL (Cont.)**

Top and bottom of pocket filler is square cut.

Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in vertical at required locations.

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014




**STACK INTERMEDIATE VERTICAL PREPARATION WITH PARTITION WALL BOTH SIDES**

Cope top of intermediate vertical as shown below.

Bottom of vertical is square cut.

Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in vertical at required locations.

Cope top of snap-in stop as shown below, bottom of stop is square cut.




Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

**STACK INTERMEDIATE VERTICAL PREPARATION WITH PARTITION WALL BOTH SIDES (Cont.)**

Top and bottom of pocket filler is square cut.

Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in vertical at required locations.





Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

**INTERMEDIATE VERTICAL PREP WITH 4" HIGH SILL**

Insert Drill Jig 530200 into vertical mullion glazing pocket and position as shown to prep for (530019) 4" high sill.  
 Position top of drill jig 4" from bottom of mullion to locate and drill (2) 0.228 dia. holes at A and B.  
 Position top of drill jig 2.562" from bottom of mullion to locate and drill (2) 0.228 dia. holes at C and D.




Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
 © Kawneer Company, Inc. 2014

**HEAD PREPARATION FOR VERTICAL ATTACHMENT**

Drill (2) 0.288 dia. holes for screw spline attachment at locations shown.


Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in head at required locations.



**SILL PREPARATION FOR VERTICAL ATTACHMENT**

Drill (2) 0.288 dia. holes for screw spline attachment at locations shown.

Using the 530200 drill jig, drill 0.288 dia. holes for spline screws in sill at required locations.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014


**DOOR JAMB PREPARATION AT DOOR HEADER**

Cope top of door jamb as shown below, bottom of door jamb is square cut.

At transom head drill (2) 0.625 dia. clearance holes in inner wall of door jamb.

Then drill (2) 0.228 dia. holes for spline screws in outer wall of door jamb at locations shown.

Cope top of snap-in stop as shown below, bottom of stop is square cut.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014



**DOOR JAMB PREPARATION FOR TRANSOM**


Cope top of door jamb as shown below, bottom of door jamb is square cut.

At head drill (2) 0.625 dia. clearance holes in inner wall of door jamb.

Then drill (2) 0.228 dia. holes for spline screws in outer wall of door jamb at locations shown.

At transom drill (4) 0.147 dia. holes in door jamb at locations shown for shear block attachment.

Cope top of snap-in stop as shown below, bottom of stop is square cut.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014


**DOOR JAMB PREP AT DOOR HEADER WITH SIDELITE**

Cope top of door jamb as shown below, bottom of door jamb is square cut.

At door header drill (2) 0.625 dia. clearance holes in inner wall of door jamb.

Then drill (2) 0.228 dia. holes for spline screws in outer wall of door jamb at locations shown.

Cope top of snap-in door stop as show, bottom of snap-in stop is square cut.




Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

**DOOR JAMB PREP AT DOOR HEADER WITH SIDELITE (Cont.)**

Pocket filler is square cut at head and sill.

Using the 530200 drill jig, drill (2) 0.228 dia. holes in pocket filler for spline screws at required locations.



NOTE:  
FOR 4" HIGH SILL PREP SEE NEXT PAGE.


Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

**DOOR JAMB PREP AT DOOR HEADER WITH 4" HIGH SILL , WITH SIDELITE (Cont.)**

Pocket filler is square cut at head and sill.

Using the 530200 drill jig, drill (2) 0.228 dia. holes in pocket filler for spline screws at required locations.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.





© Kawneer Company, Inc. 2014

**DOOR JAMB PREP WITH DOOR HEADER AT SIDELITE WITH PARTITION WALL**

Cope top of door jamb as shown below, bottom of jamb is square cut.

Prep top of door jamb for spline screws by drilling (2) 0.625 dia. clearance holes into inner wall. Then drill (2) 0.228 dia. holes into outer wall at locations shown.

Cope top of snap-in stop as shown, bottom of snap-in stop is square cut. Weathering must be cut back to bottom of sill snap-in stop at partition wall.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.


Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

### DOOR JAMB PREP WITH DOOR HEADER AT SIDELITE WITH PARTITION WALL (Cont.)

Pocket filler is square cut at head and sill.

Using the 530200 drill jig, drill (2) 0.228 dia. holes in pocket filler for spline screws at required locations.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014



**DOOR JAMB PREP WITH TRANSOM AT SIDELITE WITH PARTITION WALL**

Cope top of door jamb as shown below, bottom of jamb is square cut.

At head drill (2) 0.625 dia. clearance holes in inner wall of door jamb at locations shown. Then drill (2) 0.228 dia. holes for spline screws in outer wall of door jamb at locations shown.

At transom drill (4) 0.147 dia. holes in door jamb at locations shown for shear block attachment.

Cope top of snap-in stop as shown, bottom of snap-in stop is square cut. Weathering must be cut back to bottom of sill snap-in stop at partition wall.




Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

**DOOR JAMB PREP WITH TRANSOM AT SIDELITE WITH PARTITION WALL (Cont.)**

Pocket filler at is square cut at head and sill.

Using the 530200 drill jig, drill (2) 0.228 dia. holes in pocket filler for spline screws at required locations.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014





**COMMON DOOR JAMB PREP WITH DOOR HEADER**

Cope top of common door jamb as shown, bottom of door jamb is square cut.

Drill (2) 0.182 dia. holes on both sides of door jamb at locations shown for clip attachment.

At bottom of door jamb notch out interior side of jamb per dimensions shown to allow anchor installation.

At bottom of door jamb drill (1) 0.201 dia. thru hole with 0.385 dia. X 82° countersink on each side.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.


Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

**COMMON DOOR JAMB PREP WITH TRANSOM**

At top of door jamb drill (1) 0.201dia. thru hole with 0.385 dia. X 82° countersink on each side.

At bottom of door jamb notch out interior side of jamb per dimensions shown to allow anchor installation.

At bottom of door jamb drill (1) 0.201dia. thru hole with 0.385 dia. X 82° countersink on each side.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

**COMMON DOOR JAMB PREP WITH TRANSOM**


Top of common door jamb is square cut.

At top of door jamb drill (1) 0.201 dia. thru hole with 0.385 dia. X 82° countersink on each side.

At transom drill (4) 0.147 dia. holes in door jamb at locations shown for shear block attachment.

At bottom of door jamb notch out interior side of jamb per dimensions shown to allow anchor installation.

At bottom of door jamb drill (1) 0.201dia. thru hole with 0.385 dia. X 82° countersink on each side.




Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014


**DOOR HEADER PREP FOR COMMON DOOR JAMB**

Prep door header from centerline of common door jamb location, drill (4) 0.288 dia. holes at locations shown.



**TRANSOM PREP FOR COMMON DOOR JAMB**

Prep transom at centerline of common door, drill (2) 0.185 dia. holes at locations shown.




Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

**TRANSOM HEAD PREP FOR COMMON DOOR JAMB**

Prep transom head at centerline of common door, drill (2) 0.185 dia. holes at locations shown.





Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.



Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

**DETAIL OF TRANSOM STOP ASSEMBLY**




**DOOR JAMB (TRANSOM SIMILAR)**  
530020 SHOWN  
061222 DASHED



**VERTICAL CUT SIZES**



DRILL HOLES FOR #10 FHTF FASTENER  
AT 1" FROM EACH END AND 9" O.C.



**HORIZONTAL CUT SIZES**

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014

DETAIL OF (069177) DOOR STOP ASSEMBLY

DOOR JAMB (TRANSOM SIMILAR)  
530020 SHOWN  
061222 DASHED

DIMENSION "X"

FOR 1-3/4" DOORS: DIMENSION "X" = 1.969  
FOR 2" DOORS: DIMENSION "X" = 2.219



DOOR OPENING - 0.531"

DOOR OPENING - 0.375"


VERTICAL CUT SIZES



COVER  
0.050

0.125

0.531 (TOP OF BASE)  
0.375 (TOP OF COVER)



DIMENSION "X"

0.459  
HOLE CENTERLINE

TOP

1.000  
9" O.C. (TYP.)


1.000

BOTTOM

DRILL HOLES FOR #8 PHST FASTENER  
AT 1" FROM EACH END AND 9" O.C.  
(USE HOLES IN BASE AS TEMPLATE)




COVER



DOOR OPENING - .03125"



BASE



DOOR OPENING - .03125"

HORIZONTAL CUT SIZES

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

**FRAME ASSEMBLY**

1. Using 028856 (#12 x 1-1/8" PHTF) spline screws, attach head and sill to intermediate vertical.

Drive first fastener mid-way into screw spline, insert and drive second fastener into remaining screw spline.

**NOTE:** Screw spline fasteners should be installed with a non-hammer/non-impact screw gun. The fastener head shall be snug against the extrusion but not over tightened. Over tightening fasteners may cause crazing in the anodized finishes along the length of the screw spline above the fastener location. Adjust torque setting on screw gun accordingly.


2. Attach horizontal to intermediate vertical.

3. Attach horizontal to vertical pocket filler.

4. Snap pocket filler into vertical member.

5. Attach jamb to head, horizontal and sill members.

**NOTE:** Build one bay at a time, fastening first bay then installing next.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014



**FRAME ASSEMBLY AT STACK MULLION**


1. Using 028856 (#12 x 1-1/8" PHTF) spline screws, attach head, horizontal and sill to intermediate vertical.

Drive first fastener mid-way into screw spline, insert and drive second fastener into remaining screw spline.

**NOTE:** Screw spline fasteners should be installed with a non-hammer/non-impact screw gun. The fastener head shall be snug against the extrusion but not over tightened. Over tightening fasteners may cause crazing in the anodized finishes along the length of the screw spline above the fastener location. Adjust torque setting on screw gun accordingly.

2. Attach head, horizontal and sill to vertical pocket filler.

3. Pocket filler will snap into vertical member when frame is installed.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

**FRAME ASSEMBLY AT STACK MULLION WITH PARTITION WALL**


1. Using 028856 (#12 x 1-1/8" PHTF) spline screws, attach head, horizontal and sill to intermediate vertical.

Drive first fastener mid-way into screw spline, insert and drive second fastener into remaining screw spline.

**NOTE:** Screw spline fasteners should be installed with a non-hammer/non-impact screw gun. The fastener head shall be snug against the extrusion but not over tightened. Over tightening fasteners may cause crazing in the anodized finishes along the length of the screw spline above the fastener location. Adjust torque setting on screw gun accordingly.

2. Attach head, horizontal and sill to vertical pocket filler.

3. Pocket filler will snap into vertical member when frame is installed.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.


© Kawneer Company, Inc. 2014

**DOOR FRAME ASSEMBLY WITH DOOR HEADER**

1. Using 028856 (#12 x 1-1/8" PHTF) spline screws, attach door header to door jambs.

Drive first fastener mid-way into screw spline, insert and drive second fastener into remaining screw spline.

**NOTE:** Screw spline fasteners should be installed with a non-hammer/non-impact screw gun. The fastener head shall be snug against the extrusion but not over tightened. Over tightening fasteners may cause crazing in the anodized finishes along the length of the screw spline above the fastener location. Adjust torque setting on screw gun accordingly.




**DOOR FRAME ASSEMBLY WITH TRANSOM**

1. Using 028856 (#12 x 1-1/8" PHTF) spline screws, attach head to door jambs.

Drive first fastener mid-way into screw spline, insert and drive second fastener into remaining screw spline.

**NOTE:** Screw spline fasteners should be installed with a non-hammer/non-impact screw gun. The fastener head shall be snug against the extrusion but not over tightened. Over tightening fasteners may cause crazing in the anodized finishes along the length of the screw spline above the fastener location. Adjust torque setting on screw gun accordingly.

2. Attach transom to door jambs with shear blocks.




**DOOR FRAME ASSEMBLY WITH SIDELITE**

1. Using 028856 (#12 x 1-1/8" PHTF) spline screws, attach door jamb pocket filler to head, horizontal and sill.

Drive first fastener mid-way into screw spline, insert and drive second fastener into remaining screw spline.

**NOTE:** Screw spline fasteners should be installed with a non-hammer/non-impact screw gun. The fastener head shall be snug against the extrusion but not over tightened. Over tightening fasteners may cause crazing in the anodized finishes along the length of the screw spline above the fastener location. Adjust torque setting on screw gun accordingly.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014


**COMMON DOOR JAMB FRAME ASSEMBLY WITH DOOR HEADER**

1. Attach door header to door jambs with 028856 (#12 x 1-1/8" PHTF) spline screws.

Drive first fastener mid-way into screw spline, insert and drive second fastener into remaining screw spline


**NOTE:** Screw spline fasteners should be installed with a non-hammer/non-impact screw gun. The fastener head shall be snug against the extrusion but not over tightened. Over tightening fasteners may cause crazing in the anodized finishes along the length of the screw spline above the fastener location. Adjust torque setting on screw gun accordingly.

Attach common door jamb to door header with (530501) angle clip package.



**COMMON DOOR FRAME ASSEMBLY WITH TRANSOM**

1. Attach transom to door jambs with shear block.
2. Attach (530502) shear block pkg. to transom with pan head screws provided.
3. Insert common door jamb over shear block and fasten with flat head screws provided.




**COMMON DOOR JAMB FRAME ASSEMBLY WITH TRANSOM**

1. Attach transom head to door jambs with 028856 (#12 x 1-1/8" PHTF) spline screws.

Drive first fastener mid-way into screw spline, insert and drive second fastener into remaining screw spline.

**NOTE:** Screw spline fasteners should be installed with a non-hammer/non-impact screw gun. The fastener head shall be snug against the extrusion but not over tightened. Over tightening fasteners may cause crazing in the anodized finishes along the length of the screw spline above the fastener location. Adjust torque setting on screw gun accordingly.

2. Attach (530502) shear block pkg. to transom head with pan head screws provided.
3. Insert common door jamb over (530502) shear block pkg. and fasten with flat head screws provided.
4. Attach transom bar to common door jam with shear block on both sides.




Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

## FRAME ASSEMBLY


This framing system is designed to be fabricated and assembled on the floor in bays, then each bay is raised into the opening position and joined with the next bay. Once elevation is anchored into the opening, the head, jambs and partition sill members are captured with a snap-in face member to secure the entire opening.




Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014


Shim and anchor the frame in a plum and level condition after the frame is set into place.




**HEAD**



**JAMB**




**SILL AT PARTITION WALL**



**SILL**

**SHIM INSTALLATION**

Drill and countersink perimeter fastener holes in frame members, place shims at perimeter anchor locations. For (530011) sill, match drill hole through (530301) shim support. Place shim between (530301) pocket filler and perimeter condition at perimeter anchor locations.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.




Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014



**PERIMETER FASTENERS AT DOOR JAMB**

There are three options for anchoring the door jamb to the perimeter condition:

1. Drill and countersink holes in door jamb for perimeter fasteners.
2. Drill 1/2" counter bore holes in door jamb and insert hole plug (027633) after installation.
3. Counter bore holes in door jamb for perimeter fasteners, then install door stop, which will cover these holes.









Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

**COMMON DOOR JAMB INSTALLATION AT SILL ANCHOR**

Locate sill anchor at centerline of common door jamb and install on floor.  
 Slide bottom of door jamb over sill anchor, anchor should be flush with face of frame.  
 Fasten door jamb to anchor with flat head fasteners provided.





Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
 © Kawneer Company, Inc. 2014

**INSTALLATION OF INTERIOR SNAP-IN COVERS**

1. Install vertical snap-in stops first then horizontal stops.
2. Insert leg of snap-in stop into frame, use a clamp to start and hold stop, using a wood or plastic clamp will prevent scratching the finish. Tap snap-in stop into place with a mallet and wood block.



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014


**GASKET INSTALLATION**

- 1: Cut horizontal and vertical gaskets to an approximate length of D.L.O. + 1/4" per foot of D.L.O..
- 2: Install gaskets on the side of frame **opposite** glass stop first.

Insert gaskets into the horizontal members first starting at the ends and work toward the center as shown. (see Figure 1)

Install vertical gaskets into the same side of frame after horizontal gaskets are in place in the same manner.




- 3: Position setting blocks at points under glass as required.
- 4: Install glass into frame using standard flush glazing technique.
- 5: Install horizontal and vertical gasket into **glass stop side** of frame in the same manner as described in Step #2.




(Figure 1)

**"W" SIDE BLOCKS**

One "W" Side Block should be installed in the deep pocket of the mullion of each lite of glass in the opening.

**SIDE BLOCK INSTALLATION**

FLATTEN BLOCK & SLIDE  
BETWEEN REGLET AND  
GLASS LITE





INSERT BETWEEN  
GLASS AND FRAME

"W" Block will expand and wedge between walls of glazing pocket and prevent glass from shifting into the deep pocket.

**NOTE:** If deglazing of lite is required after "W" Block is installed, remove both interior and exterior weathering and use hook to pull "W" Block out of pocket.



**INSTALLATION OF SILL / HORIZONTAL GLASS STOP**

1. Insert leg of glass stop into frame and push down to snap in place.



**INSTALLATION OF EXTERIOR GASKET**

1. Install exterior gasket in same manner as the interior gasket.



**GLAZING CHART**

Infill Thickness	Weathering (Both Sides)
1/8"	027077 (Heavy)
1/4"	027074 (Standard)
3/8"	027076 (Light)

**I.D. Marks**

None for Standard

1 for Light

3 for Heavy



027074 (Standard)



027076 (Light)





027077 (Heavy)

**NOTE:** For infill thickness in 1/16" increments or oversize and undersize glass, use a combination of the standard (027074) with either the light (027076) or heavy (027077) gaskets.

**NOTES:**

- 1) THESE FORMULAS DO NOT ALLOW FOR UNDERSIZE OR OUT OF SQUARE DAYLITE OPENINGS.
- 2) THE GLASS MANUFACTURER MUST INDICATE THE SPECIFIC GLAZING REQUIREMENTS FOR THE MATERIAL BEING USED.

**DOOR STOP INSTALLATION**



THE COVER MOULDING, 060315, SHOULD BE SNAPPED INTO PLACE WITH HAND PRESSURE ONLY, USING CARE NOT TO DENT THE PART. IF DONE CAREFULLY, THE COVER CAN BE REMOVED AND REPLACED WITHOUT DAMAGE. LUBRICANT APPLIED TO THE LOCKING LEG OF THE BASE MOULDING WILL REDUCE ASSEMBLY FORCE.

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

### TRANSOM STOP INSTALLATION



### SNAP IN SEQUENCE


THE COVER MOULDING, 450022, SHOULD BE SNAPPED INTO PLACE WITH HAND PRESSURE ONLY, USING CARE NOT TO DENT THE PART. IF DONE CAREFULLY, THE COVER CAN BE REMOVED AND REPLACED WITHOUT DAMAGE. LUBRICANT APPLIED TO THE LOCKING LEG OF THE BASE MOULDING WILL REDUCE ASSEMBLY FORCE.

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.


Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

D.L.O. (DayLight Opening) + 3/4 for capture systems.



D.L.O. (DayLight Opening) - 1-3/8" width and - 5/16" height at transom lites



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.  
© Kawneer Company, Inc. 2014



Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014

Laws and building and safety codes governing the design and use of glazed entrance, window, and curtain wall products vary widely. Kawneer does not control the selection of product configurations, operating hardware, or glazing materials, and assumes no responsibility therefor.

Kawneer reserves the right to change configuration without prior notice when deemed necessary for product improvement.

© Kawneer Company, Inc. 2014



KAWNEER COMPANY, INC.  
TECHNOLOGY PARK/ATLANTA  
555 GUTHRIDGE COURT  
NORCROSS, GEORGIA 30092